

D RC-FERNBEDIENUNG für LED-Produkte

In der 1. Ebene können:

mit COL+ / COL- 20 fest voreingestellte Farben ausgewählt werden: 16 „Regenbogenfarben“ und 4 „Weiss-Farben“.

Mit PRG+ / PRG- können 12 Programme ausgewählt werden:

- 1.) Festfarbe (letzte gespeicherte Festfarbe)
- 2.) Normaler Farbwechsel (Standard Farbtabelle, 5 Sekunden pro Farbe)
- 3.) Mittlerer Farbwechsel (Standard Farbtabelle, 20 Sekunden pro Farbe)
- 4.) Langsamer Farbwechsel (Standard Farbtabelle, 40 Sekunden pro Farbe)
- 5.) „Blob“: Zufällig aufblendende Farben aus der Standard Farbtabelle
- 6.) „LSD“: Rasch überblendende, zufällige Farben aus der Standard Farbtabelle
- 7.) „Fire“: Simulation eines brennenden Feuers (Rot/Orange)
- 8.) „Flashes“: Zufällige Blitze über dunklem Blau (wirkt sehr gut bei mehreren Modulen)
- 9.) „Bursts“: Zufällig blitzende Farben aus der Standard Farbtabelle
- 10.) Benutzerprogramm 1 (Kann per PC verändert werden, Voreinstellung: Rasch wechselnde Farben)
- 11.) Benutzerprogramm 2 (Kann per PC verändert werden, Voreinstellung: Rot-Grün-Blau)
- 12.) Benutzerprogramm 3 (Kann per PC verändert werden, Voreinstellung: Aufblendende Kombinationsfarben)

Die 2. Ebene

kann erreicht werden durch Drücken der mittleren Taste (SHIFT, gleichzeitig oder zuerst):

Mit DIM+ / DIM- kann der Dimmer in 8 Schritten eingestellt werden. Der Dimmer gilt für alle Programme.

Mit OFF kann das Modul abgeschaltet werden.

Mit SAVE+OFF kann das Modul abgeschaltet werden, die Einstellungen und die aktuelle Farbe werden aber gespeichert, so dass sie auch direkt nach Anschalten des Stromes erscheinen.

Wurde das Modul abgeschaltet, wird mit SHIFT der letzte Zustand vor dem Ausschalten hergestellt

Technische Daten

Funkfrequenz: 868.3 Mhz (lizenzfrei in der EU, Schweiz, Norwegen und Island)

Stromversorgung: 2 Batterien „Lady“ / „LR03“ / „AAA“ mit 1.5 Volt (Alkali oder Alkali-Mangan)

GB RC-REMOTE CONTROL for LED products

Top level:

COL+ / COL- select 20 predefined colours: 16 rainbow colours and 4 white colours (with different nuances).

PRG+ / PRG- select 12 different effects:

- 1.) Fixed Colour (last saved fixed colour)
- 2.) Normal Colour Change (all 8 colours of the standard colour table, 5 seconds per colour)
- 3.) Medium Colour Change (all 8 colours of the standard colour table, 20 seconds per colour)
- 4.) Slow Colour Change (all 8 colours of the standard colour table, 40 seconds per colour)
- 5.) „Blob“: Randomly uplighted/dimmed colours (from the 8 colours of the standard colour table)
- 6.) „LSD“: Randomly changing colours (from the 8 colours of the standard colour table)
- 7.) „Fire“: Simulation of a burning fire (red and orange)
- 8.) „Flashes“: Bright random flashes over a deep blue (looks very good with several Chromoflex RC)
- 9.) „Bursts“: Randomly selected, non-synchronised flashes (from the 8 colours of the standard colour table)
- 10.) User Program 1 (can only be modified with the PC software, preset: 8 colours with fast changing)
- 11.) User Program 2 (can only be modified with the PC software, preset: red-green-blue)
- 12.) User Program 3 (can only be modified with the PC software, preset: 3 uplighted/dimmed combined colours)

The 2nd level

can be activated by pressing the button in the middle (SHIFT, at the same time with the other or first):

DIM+ / DIM- select the 8 level dimming. The dimming level is valid for all effects.

OFF switches off all modules in the network.

With SAVE+OFF all modules are switched off too, but all settings (dimmer, effect, fixed colour) are saved in the modules's memory and will be recalled after power on.

If the modules have been switched off, pressing SHIFT will restore the last state.

Technical Data

Radio frequency: 868.3 Mhz (license free in EC, Switzerland, Norway and Iceland)

Batteries: 2 batteries, type „Lady“ / „LR03“ / „AAA“ with 1.5 Volt (Alkaline)

